CRIUS®

Water Quality Analyzer Water Quality Monitor Water Quality Controller Water Quality Instrument



Superior Communications

Part of a range of controllers, the CRIUS® is the big brother of the $\textsc{CRONOS}^{\textsc{\tiny{B}}}$ and offers more sensor connections, more functionality and more flexibility with a color screen and optional built in 3G modem. The CRIUS® is an attractively priced, top of the range instrument controller. Optional comms packages allow Profibus, Modbus ASCII, Modbus RTU, Modbus TCP and others.

More Sensors. More Control

CRIUS® is equipped with the capability to connect up to 4 sensors of any type with optional analogue outputs and relays. 4 sensors not enough? Simply connect up to 4 $\textsc{CRIUS}^{\textsc{®}}$ together all using the same display and communications. Equipped with datalogging as standard and multiple PID loops as options, CRIUS® is very able to control complex water treatment processes at a fraction of the cost of other controllers.

Easier To Use

With simple 'plug & play' inputs and outputs, intuitive display and button control, and with an individual manual configured to be the same as your analyzer, the CRIUS® makes setup and ongoing use simple and easy.

Better Security

With all users having their own log on, and with three levels of instrument and remote access security, you can use CRIUS® with all of its superior functionality with confidence.

CRIUS® + **Sensors** = **Product Name**

Free Chlorine Analyzer Total Chlorine Monitor Chlorine Dioxide Analyzer Ozone Monitor Dissolved Oxygen Meter Suspended Solids Monitor Streaming Current Monitor pH Analyzer **ORP** Analyzer Organics Monitor Biofilm Monitor Online Conductivity Monitor Particle Counter Filter Monitor (Particle Counter) FilterSense Coagulation Controller **Turbidity Monitor**

HaloSense **HaloSense DioSense** OzoSense **OxySense** SoliSense **StreamerSense** pHSense **ORPSense** UV254Sense **BioSense** ConductiSense **CounterSense** CoagSense **TurbSense**

Each 'Sense' analyzer has its own brochure, detailing applications and common accessories. Please click on the product name above if you are online. If not, please visit the website to access all Pi's product brochures.


	CRONOS®	CRIUS ®
Highest quality sensors	•	•
Multilingual	•	•
System logger	•	•
On display trending	•	•
Event logger	•	•
Download logs	Optional	•
PID controls	Optional	Optional
Up to 2 sensors	•	•
Up to 4 sensors		•
Expandable up to 16 sensors		Optional
Analogue outputs V and mA	•	•
Isolated universal inputs & outputs	s •	•
Large high resolution display	•	•
Color display	Optional	•
Up to 8 relays	•	•
Expandable up to 32 relays		Optional
Up to 8 digital inputs	•	•
Expandable up to 32 digital inputs		Optional
Remote internet access		Optional
GSM/GPRS/3G integrated modem		Optional
Remote Access LAN		Optional
Profibus	Optional	Optional
Modbus ASCII/RTU serial	Optional	Optional
Modbus TCP (LAN enabled)	Optional	Optional
AC/DC (110-240VAC, 12VDC)	•	•
Wall and Panel mountable	•	•
Pole and handrail mountable	•	•
IP65/Nema 4X enclosure	•	•
Fire retardant ABS Enclosure	•	•










Dimensions







Mounting Options









*All subject to change without notice

Specification*

CRIUS®

Power Requirements 100-240 VAC/0.25 A or 12 VDC/0.8 A

Any non pictogram by request Languages Any Latin, Cyrillic, Hellenic

Inputs Up to 4 configurable sensor inputs (expandable to 16 inputs); 4-20 mA, 4-20 mA loop-powered,

0-2 VDC, +/- 1200 mV for pH, ORP, or ISEs, PT100, potentiometric, pulse and Modbus. Unused

sensor inputs can be used as outputs. Up to 8 digital inputs (expandable to 32)

Outputs Up to 4 dedicated configurable analogue outputs (expandable to 16 outputs), 0-20mA, 4-20mA,

0-1 VDC, 0-10 VDC, 1-10 VDC. Up to 8 SPDT electromechanical relays (expandable up to 32

relays) rated 10A at 250 VAC and 5A at 30 VDC

Alarms 2 user configurable alarms with deadband and delay for each measurement and control output.

Thresholds 2 user configurable thresholds (for control) with deadband and delay for each

measurement and control output

PID Configurable flow proportional PID - multiple loops

Communication (Optional) Modbus ASCII/RTU (RS485)

Profibus DP

Modbus TCP (Ethernet)

2G/3G Modem

All user configuration is stored in non-volatile on-board flash memory **Memory Backup**

Enclosure ABS flame retardant

IP65, Nema 4X

Dimensions (mm) 230 x 309 x 103 4.3", 480 x 272, 24 bit color Display

Weight 2 kg

Warranty 12 months from date of purchase (longer warranty optional)

Data Logging Internal - Single Parameter, downloadable data logs or status message logs over 1 million







